

# LZF

AIR A



Sellesse valgustisse saab panna järgmiste energiaklasside lampe:

A<sup>++</sup>

A<sup>+</sup>

A

B

~~C~~

~~D~~

~~E~~

